Access the following URL link:

https://www.csm.de/us

1.- Click on "DOWNLOADS"



2.- Click on "SOFTWARE DOWNLOADS"



Overview		Number of Categories:
	Software Downloads Our software for CSM measurement modules CSMconfig (with CSMview) as well as our software for CSM data loggers (UniCAN 3, UniCAN 2 Professional and UniCAN 2) and Drives (Omnidrive) can be found here.	Subcategories: 3 Files: 14
	Datasheets Click here for all CSM product data sheets (CAN- and EtherCAT®-based measurement modules, data logger and drives as well as current sensores).	Subcategories: 8 Files: 56

3.- Select "CARDS AND DRIVES"

Fields of applica	tion Products	Support	Downloads	News	Company	Contact									<
				Local And	a sectored the					F		9	6	Ś	Street St.
You are here: Downlo	oads / Software Do	wnloads													
Downloads	5														
Software Do	wnloads														
Our software for C UniCAN 2) and Dri				th CSMvie	ew) as well a	as our softw	vare for CS	SM data lo	oggers (l	JniCAN 3,	UniCAN 2	Profession	al and		
Subcategories:															
	surement Techno iguration softwa		ers for CSM me	easureme	ent technolo	ogy and CAN	l <mark>in</mark> terface	es.							
)	Files: 3			
	Data Logger powerful configu	ration coffe	varo for the U		ios										
	powerrut configu	ration sort	vare for the of	IIICAN SEI	les.)	Files: 1			
	<mark>is and Drives</mark> er software for th	o card road	lors OmniDriv	and Col	tdrivo ac w	all as the D(Card Ma	nador							
	er sontware for ti	ie card fedu		e and SUI	turive ds W	en as the Pt	Card Md	nagel.			1	Files: 10			

4.- Select "OMNIDRIVE PROFESSIONAL" (USB/USB2) WINDOWS

Fields of application	Products Support Downloads News Company Contact	
	s ard readers OmniDrive and Softdrive as well as the PC Card Manager.	
Files:		
OmniDrive Profes	sional (USB/USB2) Windows	- 🛃 Download
 OmniDrive USB2 Profe OmniDrive USB2 LF OmniDrive USB2 LF/SI OmniDrive USB2 CF/SI OmniDrive USB2 CF/SI OmniDrive USB2 LF in OmniDrive USB2 Profes OmniDrive USB LF OmniDrive USB LF/SD OmniDrive USB CF/SI) Itern ern Sional	
System requirements: W XP (32- and 64-bit)	indows 10 (32- and 64-bit), Windows 8.1 (32- and 64-bit), Windows 8 (32- and 64-bit), Windows 7 (32- ar	d 64-bit), Vista (32- and 64-bit)
Version 3.3.4	Language English Size 994.29 KB	

5.- PLUG IN OMNI DRIVE

6.- Open Zip (double click)

oupi334_x86_AMD....zip

7.- Open "Setup" application

doc	File folder		
License	Text Document	2 KB	No
Cliesmich	Chrome HTML Document	10 KB	No
Lizenz	Text Document	2 KB	No
💿 Readme	Chrome HTML Document	9 KB	No
🔳 setup	Application	947 KB	No

8.- Click on "RUN"

Open File	- Security War	ning	×
Do you	want to run tl	his file?	
	Name:	l\Temp\Temp1_oupi334_x86_AMD64 (12).zip\setup.exe	e
	Publisher:	CSM Computer-Systeme-Messtechnik GmbH	
	Туре:	Application	
	From:	C:\Users\H320571\AppData\Local\Temp\Temp1_oupi3.	
		Run Cancel]
۲		om the Internet can be useful, this file type can potentiall omputer. Only run software from publishers you trust. isk?	у

9.- Allow to make changes and select language

Select Se	etup Language	\times
2	Select the language to use during the installation:	
	English	\sim
	OK Cance	9

10.- "CLICK ON NEXT"



11.- Accept agreement and click "NEXT"

Setup - OmniDrive USB Professional —		\times
License Agreement Please read the following important information before continuing.		
Please read the following License Agreement. You must accept the terms agreement before continuing with the installation.	of this	
LICENSE AGREEMENT		^
III Please read carefully before using OmniDrive USB III IF YOU DO NOT AGREE WITH THE TERMS OF THIS LICENSE AGREEMEN		
MUST NOT USE OmniDrive USB. WITH USING THE PRODUCT THE TERMS LICENSE AGREEMENT ARE IMPLICITELY ACCEPTED.	S OF THE	
 (I) Ownership and Copyright Software and accompanying documentation are properties of CSM Gmb¹ 	н,	~
 I accept the agreement 		
○ I do not accept the agreement		
< Back Next >	(Cancel

12.- Click "NEXT"

🚔 Setup - OmniDrive USB Professional	-		×
Select Destination Location Where should OmniDrive USB Professional be installed?		<	
Setup will install OmniDrive USB Professional into the followi	ing folde	r.	
To continue, click Next. If you would like to select a different folder,	click Bro	wse.	
C:\Program Files (x86)\OmniDrive USB2 Pro	Br	owse	
At least 2.9 MB of free disk space is required.			
< Back Nex	t>	Can	cel

13.- Click "INSTALL"



14.- Click "NO" and "NEXT"



15.- Click "NEXT"

🛃 Setup - OmniDrive USB Professional	_		\times
Please connect the OmniDrive USB to your PC now! Wait until windows has finished its driver installation.		<	
The CSM driver will be installed subsequently.			
< Back Ne	xt >	<u> </u>	
< Back Ne	xt>		

16.- Click "YES"

IT Secu	rity Policy		×			
Confirm Execution						
You are about to run this unapproved Executable that requires elevated rights. Any you sure you want to proceed and have your actions audited? WksOps-OCS-Defendpoint-V1. 1.Medium FlexibilityWksOps-OCS-Defendpoint-V1. 1.(Default Rule) Any Trusted UAC Prompt						
	Program Name Program Publisher Program Path	OmniDrive USB Setup/Uninstall help CSM GmbH c:\program files (x86)\omnidrive usl				
		Yes	No			

17.- Click "INSTALL"

E Windows Security	\times
Would you like to install this device software?	
Name: CSM GmbH Universal Serial Bus controller Publisher: CSM GmbH	
Always trust software from "CSM GmbH". Install Don't Install	I
You should only install driver software from publishers you trust. <u>How can I decide which device software is safe to install?</u>	

18.- Click "FINISH"

🚖 Setup - OmniDrive USB Professional			_					
	Completing the OmniDrive USB Professional Setup Wizard							
	Setup has finished installing OmniDrive USB Professional on your computer. The application may be launched by selecting the installed icons.							
	Click Finish to exit Setup.							
	< Back	Finish						